

## **Addonics Mini DigiDrive, 7-in-1 Flash Media Drive Installation Manual** **(Model No. AESDMD4)**

Thank you for purchasing Addonics Mini DigiDrive. This drive is capable of reading all current Flash media including Compact Flash Type I and II, Smart media, Memory Stick, Multimedia Card, Secure Digital Card, IBM Micro drive etc. This drive is to be used for all systems running on the Intel or AMD (or equivalent) Microprocessors.

### **Minimum System Requirements:**

- Ø Windows 98SE, Me, 2000 and XP
- Ø 32 MB of RAM
- Ø 233MHz Processor
- Ø USB port
- Ø CD-ROM Drive

### **Software Installation**


Installation on PC running Windows OS

1. Turn on your computer. If it is already on, save any work in progress and close any open programs.
2. Insert the Mini DigiDrive Installation CD into the CD-ROM drive of your computer.
3. Open "My Computer" on your desktop, and then double-click the CD drive icon.
4. Double-Click "SETUP.EXE" and follow the instructions on your computer screen to install the drivers for your Mini DigiDrive.
5. Restart your computer when prompted.
6. Open "My Computer" to view icons of media cards that are inserted in the Mini DigiDrive. Read and write to these media using the same method as that used for moving data to and from any storage device.



### **Hardware installatin for (Windows 98SE, ME, XP and 2000Pro)**

1. Locate an USB port from the computer and plug In the USB connector from the Mini Digidrive.
2. Windows will now detect a new hardware and will install all required driver for the Mini Digidrive.
3. Go to My Computer and you should see Four New Unique Drive letter Icons.



4. You may now use the Mini Digidrive.

### **(MS, MMC, SD, SM)**

1. Insert Card with metal contact strip facing down (up for SM) and the cut out notch on the left side (right side for SM) going toward the Mini Digidrive.
2. Push gently all the way in.
3. To remove the card, merely pull the card back out. You may remove the card safely.

### **Compact Flash (CF) or IBM Micro drive**

1. Insert Card with edge, with the holes facing toward the Mini Digidrive. Making sure to line the card up with rails.
2. Push gently all the way in.
3. To remove the card, merely pull the card back out. You may remove the card safely.

### **Technical Support**

If you need assistance to get your unit functioning properly, please call Addonics Technical Support. Our technical staff will be happy to assist you, but they will need your help to do so. Calling the technical support staff without all the proper information can be both time consuming and frustrating. Please have all the information handy like the model number, operating system etc.

### **Contact Information**

Addonics Technologies  
2466 Kruse Drive  
San Jose CA, 95131  
Phone: 408-433-3899  
Fax: 408-433-3898

### **Technical Support**

Phone: 408-433-3855  
Email: [Techinfo@addonics.com](mailto:Techinfo@addonics.com)